



APPLICATION INSTRUCTIONS

CERAMIC GRAPHENE Wipe-On Exterior Protectant

STEP 1

Begin with a **clean** surface.

STEP 2

With a **dry, clean** applicator sponge or an orbital polisher, apply a thin layer of NanoCure® Ceramic Graphene Wipe-On Exterior Protectant to the vehicle's painted and chrome surfaces, as well as the headlight lenses and clear-coated factory aluminum wheels.

NOTE: Do not apply NanoCure Ceramic Graphene Wipe-On Exterior Protectant to plastic trim or black trim molding.

STEP 3

Once completely dry, use a clean microfiber towel to remove protectant haze using small, circular movements. If streaking or shadowing occurs, rub areas with a clean, damp microfiber towel, then dry them with a clean microfiber towel.

NOTE: Turn the towel as necessary so that it continues to wipe the surface to a brilliant shine.

Important: Never use a dirty microfiber towel, applicator sponge, polishing pad or trigger sprayer that has been used to apply any other chemical.



Scan this code for additional detail resources