

CORROSION PROTECTANT

STEP 1

Identify all access points to body seams in doors and deck lids and remove any rubber or plastic plugs, if present.

STEP 2

Shake NanoCure® Corrosion Protectant well and pour into the spray gun canister, filling halfway. Adjust air pressure to between 45–60 p.s.i.

STEP 3

Close all windows. Insert the spray gun wand into each access point and spray protectant using a rolling motion for smooth application throughout each panel. Coat the bottom seam of each door.



STEP 4

Spray protectant into doors, pillar posts, and the hood and trunk panels.

STEP 5

With deck lids open, spray all panel seams.

STEP 6

Wipe off excess protectant with a **clean, dry** cloth.

GUN CLEANING: The gun should be cleaned after every 2–3 uses.

Refer to the Safety Data Sheet for recommended protective gear.



Scan this code for additional detail resources