

SPRAY-ON EXTERIOR PROTECTANT

STEP 1

Begin with a **clean, dry** or **wet** vehicle. Shake product well before using.

STEP 2

Apply a fine mist of NanoCure® Spray-On Exterior Protectant to all painted surfaces, black trim molding, headlight lenses and wheels.

STEP 3

Using a **clean, dry** microfiber towel, wipe the treated surfaces to remove all excess protectant. Use a second clean, dry microfiber towel to hand buff the treated surfaces to remove any remaining streaking or hazing from the vehicle, as necessary.

NOTE: Turn the towel as necessary so that it continues to wipe the surface to a brilliant shine.



WIPE-ON EXTERIOR PROTECTANT

STEP 1

Begin with a **clean** surface.

STEP 2

With a **dry, clean** applicator sponge or an orbital polisher, apply a thin layer of NanoCure® Wipe-On Exterior Protectant to the vehicle's painted and chrome surfaces, as well as the headlight lenses and clear-coated factory aluminum wheels.

NOTE: Do not apply NanoCure Wipe-On Exterior Protectant to plastic trim or black trim molding.

STEP 3

Once completely dry, use a clean microfiber towel to remove protectant haze using small, circular movements. If streaking or shadowing occurs, rub areas with a clean, damp microfiber towel, then dry them with a clean microfiber towel.

NOTE: Turn the towel as necessary so that it continues to wipe the surface to a brilliant shine.



Important: Never use a dirty microfiber towel, applicator sponge, polishing pad, or trigger sprayer that has been used to apply any other chemical.



Scan this code for additional detail resources