



APPLICATION INSTRUCTIONS

CERAMIC GRAPHENE Spray-On Exterior Protectant

FOR WINDSHIELD

STEP 1

Begin with a **clean** surface.

NOTE: *Never use a dirty microfiber towel, applicator sponge, polishing pad, or trigger sprayer that has been used to apply any other NanoCure protectant.*

STEP 2

Apply a fine mist spray of NanoCure® Ceramic Graphene Spray-On Exterior Protectant liberally on to a paper towel, disposable foam applicator pad or microfiber towel.

STEP 3

Wipe the protectant onto the surface of the windshield in a crosshatch pattern to ensure complete coverage. Wait until the product dries – look for a light haze. (Approximately 1 minute)

STEP 4

Using a **clean, dry** microfiber towel, wipe the treated surface to remove all excess protectant. Use a second **clean, dry** microfiber towel to hand buff the treated surface to remove any remaining streaking or hazing from the vehicle, as necessary.

NOTE: *Turn the towel as necessary so that it continues to wipe the surface until clear.*

STEP 5

The windshield should appear clean and without any hazy residue. Repeat Step 4 above to remove any hazy or foggy spots.

Important: *Never use a dirty microfiber towel, applicator sponge, polishing pad, or trigger sprayer that has been used to apply any other chemical.*



Scan this code for additional detail resources