

# **APPLICATION INSTRUCTIONS**


#### **TIRE TREATMENT**

### STEP 1

Begin with clean, dry or wet tires. Shake product well before using.

## STEP 2

With a **clean**, **dry** microfiber towel, wax applicator or sponge, wipe an even coating onto all of the outside-facing surfaces of the tire.





## STEP 3

Allow the product to dry for 30 minutes before delivering the vehicle to the consumer. Advise the consumer to avoid car washes for at least 24 hours after the product application.

**Important:** Never use a dirty microfiber towel, applicator or sponge or trigger sprayer that has been used to apply any other chemical.



Scan this code for additional detail resources