

### WINDSHIELD PROTECTANT FEATURING CERAMIC GRAPHENE

#### STEP 1

Begin with a **clean** surface.

**NOTE:** Never use a dirty microfiber towel, applicator sponge, polishing pad, or trigger sprayer that has been used to apply any other NanoCure protectant.

#### STEP 2

Apply a fine mist spray of NanoCure® Windshield Protectant liberally on to a paper towel, disposable foam applicator pad or microfiber towel.



#### STEP 3

Wipe the protectant onto the surface of the windshield in a crosshatch pattern to ensure complete coverage. Wait until the product dries – look for a light haze. (Approximately 1 minute)

#### STEP 4

Wipe the windshield with a **clean, damp** microfiber towel. Then immediately wipe the windshield with a **clean, dry** microfiber towel to remove all remaining haze.

**NOTE:** Do not apply too much water to the microfiber towel. A spray-mist is all that is required.

#### STEP 5

The windshield should appear clean and without any hazy residue. Repeat Step 4 above to remove any hazy or foggy spots.

**Important:** Never use a dirty microfiber towel, applicator sponge, polishing pad, or trigger sprayer that has been used to apply any other chemical.



Scan this code for additional detail resources